# **Technical Data/ Product Specifications**

# **3** Matting Edging Low Profile

1.0	Product Description	The product is a tapered vinyl strip for application to edges of vinyl or vinyl-backed matting such as 3M <sup>™</sup> Nomad <sup>™</sup> Carpet Matting 4000, 6500, 6600, and 8850.				
2.0	Intended Use	For use on vinyl matting to provide an edge that tapers to the floor.				
3.0	Standard Sizes	Rolls: 75 ft.				
4.0	Color	Black				
5.0	Requirements	The product shall be a low profile tapered vinyl strip suitable for application to the edges of vinyl or vinyl-backed matting.				
		Detailed Requirements:				
		Property Thickness ASTM D418	<u>Typical Values</u> Minimum: 0.11 inches (2.7 mm)			
		Hardness Shore A instantaneous	Minimum: 62 Maximum: 75			
6.0	Packaging and Marking	Packaging: Rolls – one per case				
		Marking: Each carton shall be marked with product name, size, color, and manufacturer's trade name.				

7.0	Installation	0	Matting edging can be easily applied to 3M <sup>™</sup> Nomad <sup>™</sup> Carpet Matting.			
		Tools and materials needed: Utility knife Straight edge 3-4 feet long (90-120 cm) 3M <sup>™</sup> Matting Edging – Kit or Roll 3M <sup>™</sup> Matting Adhesive – one 3 U.S. fl. oz. (88 ml) tube of adhesive will apply approximately 15 ft. (450 cm) of edging.				
		For best results follow these guidelines:				
		Before applying edging, ensure that the matting and edging are relaxed and not stretched. Unroll the matting and edging and allow to reach room temperature. Do not stretch matting when applying edging.				
			Be certain sides to be edged are straight. Trim edges with a utility knife (not scissors) and a straight edge if necessary.			
		2. Cut	<ul> <li>Cut length of edging to same length as edge of mat.</li> <li>Place edging flat on the floor, grooved side up.</li> <li>Apply two beads of adhesive liberally to the top of edging flap.</li> <li>Place edge of mat on top of edging flap containing adhesive and apply moderate pressure.</li> <li>Place a weight, such as a board, along the full length of the edging to assure a maximum strength bond. Allow to dry at least eight hours before placing matting into service.</li> </ul>			
		3. Plac				
		4. App				
		to a				
8.0	Weight and Cube per Case	Si	ze	Approximate Weight	Cube	
		Ro	lls	11 lb.	0.628 cu. ft.	

# **3M Branch Sales Offices**

#### ANCHORAGE

11151 Calaska Circle Anchorage, AK 99515 Telephone: 907/522-5200 Facsimile: 907/522-1645

# CONTINENTAL UNITED STATES

Customer Service Department 3M Center Building 223-5N-07 St. Paul, MN 55144-1000 Order Entry 1-800-852-9722 Facsimile: 1-800-447-0408

### HONOLULU

4443 Malaai Street Honolulu, HI 96818 Mail to: P.O. Box 30048 Honolulu, HI 96820 Telephone: 808/422-2721 Facsimile: 808/422-9557

# **3M CANADA**

1840 Oxford Street East London, Ontario, Canada N5V 3G2 Mail to: P.O. Box 5757 London, Ontario, Canada N6A 4T1 Telephone: 800/364-3577 Facsimile: 800/479-4453

## Important Notice:

This flyer is intended to be an introductory summary. The information provided is based upon typical conditions and is believed to be reliable; however, due to the wide variety of intervening factors 3M does not warrant that the results will necessarily be obtained. All details concerning product specifications and terms of sale are available from 3M.

**3 Commercial Care Division** 3M Center St. Paul, MN 55144-1000

3M and Nomad are trademarks of 3M.

Copyright @ 2000, 3M IPC. All rights reserved. 70-0710-3534-2