

# 3

## Matting Edging

### Medium Profile

**1.0 Product Description** The product is a tapered vinyl strip for application to edges of vinyl matting such as 3M™ Nomad™ Carpet Matting 9800, 3M™ Nomad™ Scraper Matting 6050 and 6250, 3M™ Safety-Walk™ Wet Area Matting 1500 and 3200.

**2.0 Intended Use** For use on matting to provide an edge that tapers to the floor.

**3.0 Standard Sizes** Rolls: 75 ft.

**4.0 Colors** Black, Granite

**5.0 Requirements** The product shall be a medium profile tapered vinyl strip suitable for application to the edges of vinyl or vinyl-backed matting.

Detailed Requirements:

<u>Property</u>	<u>Typical Values</u>
Thickness ASTM D418	Minimum: 0.24 inches (6.0 mm)
Hardness Shore A instantaneous	Minimum: 62 Maximum: 75

**6.0 Packaging and Marking** Packaging: Rolls - one per case

Marking: Each carton shall be marked with product name, size, color, and manufacturer's trade name.

## 7.0 Installation

Matting edging can be easily applied to 3M™ Nomad™ Scraper Matting 6050 and 6250, 3M™ Nomad™ Carpet Matting 9800, and 3M™ Safety-Walk™ Cushion Matting and 3M™ Safety-Walk™ Wet Area Matting.

Tools and materials needed:

Utility knife

Straight edge, 3-4 feet long (90-120 cm)

3M™ Matting Edging – Kit or Roll

3M™ Matting Adhesive – one 3 U.S. fl. oz. (88 ml) tube of adhesive will apply approximately 15 ft. (450 cm) of edging.

For best results follow these guidelines:

Before applying edging, ensure that the matting and edging are relaxed and not stretched. Unroll the matting and edging and allow to reach room temperature. Do not stretch matting when applying edging.

1. Be certain sides to be edged are straight. Trim edges with a utility knife (not scissors) and a straight edge if necessary.
2. Cut length of edging to same length as edge of mat.
3. Place edging flat on the floor, grooved side up.
4. Apply two beads of adhesive liberally to the top of edging flap.
5. Place edge of mat on top of edging flap containing adhesive and apply moderate pressure.
6. Place a weight, such as a board, along the full length of the edging to assure a maximum strength bond. Allow to dry at least eight hours before placing matting into service.

## 8.0 Weight and Cube per Case

Size	Approximate Weight	Cube
Rolls	11 lb.	0.628 cu. ft.

### **3M Branch Sales Offices**

#### **ANCHORAGE**

11151 Calaska Circle  
Anchorage, AK 99515  
Telephone: 907/522-5200  
Facsimile: 907/522-1645

#### **CONTINENTAL UNITED STATES**

Customer Service Department  
3M Center Building 223-5N-07  
St. Paul, MN 55144-1000  
Order Entry 1-800-852-9722  
Facsimile: 1-800-447-0408

#### **HONOLULU**

4443 Malaai Street  
Honolulu, HI 96818  
Mail to: P.O. Box 30048  
Honolulu, HI 96820  
Telephone: 808/422-2721  
Facsimile: 808/422-9557

#### **3M CANADA**

1840 Oxford Street East  
London, Ontario, Canada  
N5V 3G2  
Mail to: P.O. Box 5757  
London, Ontario, Canada  
N6A 4T1  
Telephone: 800/364-3577  
Facsimile: 800/479-4453

#### **Important Notice:**

This flyer is intended to be an introductory summary. The information provided is based upon typical conditions and is believed to be reliable; however, due to the wide variety of intervening factors 3M does not warrant that the results will necessarily be obtained. All details concerning product specifications and terms of sale are available from 3M.

**3**  
**Commercial Care Division**  
3M Center  
St. Paul, MN 55144-1000

3M, Nomad, and Safety-Walk, are trademarks of 3M.

Copyright © 2000, 3M IPC. All rights reserved.  
70-0710-3593-8